



ODY-9-1 VACUUM/BOOST GAUGE

Introduction:

The Odyssey gauge series from Dakota Digital, Inc. incorporates the reliability and quality of our standard gauges, along with several unique features and easy mounting. These features include:

- A warning feature that flashes the gauge readout when outside operating limits.
- A connection for an external warning indicator that is activated when the gauge flashes.
- User adjustable warning points.
- Microprocessor stabilized readings.
- Quick-Start feature to provide accurate readings quickly after being powered up.
- Night dimming with lens label lighting.
- High Visibility VFD display for sunlight readability.

The vacuum/boost gauge will read the level of either vacuum or boost pressure at the engine.

Vacuum is created by restrictions in the air flow to the engine. The restrictions are created by the throttle, air intake, and air filter. The vacuum is highest when the vehicle is decelerating or idling. Boost is created by either a turbo charger, blower, or super charger forcing additional air into the engine. The additional air allows more fuel to be burned, increasing power.

The vacuum/boost gauge will operate and read correctly from 39 in. Hg. vacuum to 30.0 psi boost. The gauge has a user adjustable warning for high vacuum and for high boost pressure. To disable the warning, set the limits to the highest reading.


Operation:

The gauge needs only the red and black wires connected to light up. The 3 wire pin connector attaches to the mating connector on the sender. **The sender must be Dakota Digital part SEN-9-1.** The sensor will measure the pressure from a vacuum tube connected to its upper port. The lower port should be left open. When the blue wire has 12 volts, it will dim the display for night viewing. The yellow wire will provide a ground output when the gauge reading is outside the warning limits.

Setting the warning limits:

The high and low warning limits can be set to different values. Once they have been set, they are stored internally so that the gauge will retain the values even when the gauge does not have any power. These values can be set and reset as many times as desired. The procedure for setting the warning limits is as follows:

1. Make sure the key is off so the gauge is not powered.
2. Press and hold the 'SET' button. This is located behind the hole located on the back side of the gauge as shown in figure 1.
3. Turn the key on while the 'SET' button is being held.
4. Release the button. The gauge should show 'LO' and then switch to a reading between 39- and 0.0 (vacuum in in. Hg.).
5. Turn the warning adjustment pot until the desired vacuum limit is showing. The adjustment will then 3/4 rotation from stop to stop. Do not force it past either stop.
6. Press and release the 'SET' button. The gauge should show 'HI' and then switch to a reading between 0.0 and 39.0 (boost in psi).
7. Turn the warning adjustment pot until the desired boost limit is showing.
8. Press and release the 'SET' button. The gauge should show '--'. The new warning limits are now stored.
9. Turn the key off. The gauge will now operate normally when powered up again.



Using external warning indicators:


The yellow wire provides a ground trigger whenever the gauge is outside its set limits. Low current indicators (less than 1/4 A or 3 watt) can be activated directly by connecting their power wire to 12 volts and connecting their ground wire to the yellow output wire. Many gauges can share the same indicator by connecting their yellow warning wires together. In this way, when any one or more gauges are outside their limits the warning indicator will be activated.

For higher current buzzers or lights, a relay will need to be used to switch the indicator on. Dakota Digital's RLY-1 30A relay may be used for this. One of the coil wires should be connected to 12 volts and the other coil wire connected to the yellow warning wire. When the gauge is outside its limits, the relay will turn on. The relay contact wires can be used to switch the higher current.

WARNING!
CONNECTING A HIGH CURRENT
INDICATOR DIRECTLY TO THE
WARNING OUTPUT WILL DAMAGE
THE UNIT.



Wiring:

- BLACK - connect to a good ground point in the vehicle.
 - RED - connect to an accessory terminal from your fuse block.
 - BLUE - connect to the tail light circuit.
 - YELLOW - (optional) connect to warning indicator.
- 3 pin connector from gauge connects to mating connector from sensor.



Mounting:

The gauge requires a rectangular cut out that is about 2 9/16" x 1 11/16". It should be inserted into the opening from the front and the U-clamp will be installed from the back. Tighten the two nuts on the U-clamp so that the gauge is secure. Figure 2 shows the required cut out for the gauge. Figure 3 shows how the gauge mounts.



Troubleshooting guide.

Problem	Possible cause	Solution
Gauge will not light up	Red wire does not have power. Black wire is not getting a good ground. Fuse is blown.	Connect to a location that has power. Connect ground to a different location. Replace in line fuse. (2 amp only.)
Gauge lights up, but gauge displays "EE" or "--".	Gauge is damaged. Sender is not connected to gauge. Wire between gauge and sender is broken. Sender is wrong type Gauge is damaged. Sender is damaged.	Return gauge for repair. (see instructions) Attach mating connectors between and sender together. Check for pinched or damaged cable. Make sure sender is SEN-9-1. Return gauge for repair. (contact factory) Return for repair. (contact factory)
Gauge lights up, but does not read correctly.	Loose connection on red power wire. Poor ground connection. Improper vacuum hose connection. Hose connected to wrong port on sensor. Incorrect sender type.	Reconnect red wire. Move ground to different location Check where vacuum hose is connected. Check for plugged hose. Connect hose to upper port, which is the one closest to the label side. Make sure sender is the correct type (SEN-9-1). Return for repair. (contact factory)
Gauge flashes constantly.	Sender is damaged. Warning limits are not set properly.	Reset warning limits.
External warning indicator does not work.	Indicator not connected properly. Indicator does not work. Gauge output has been damaged.	Check indicator wiring connections. Repair or replace indicator. Return gauge for repair. (see instructions)
Gauge will not dim.	Blue wire is not connected correctly. Gauge is damaged.	Check wiring connections. Return gauge for repair. (contact factory)
Gauge remains dim at all times.	Blue wire is getting power all of the time. Battery is very low. Gauge is damaged.	Connect blue wire to location that only has power when the headlights are on. Recharge or replace vehicle battery. Return gauge for repair. (contact factory)

Technical specifications

Minimum operating voltage	-	7 volts
Maximum operating voltage	-	18 volts
(operating at or near maximum rating for an extended time can damage unit)		
Maximum vacuum reading	-	39 in. Hg.
Maximum vacuum reading	-	30.0 psi
Gauge Resolution	-	1 in. Hg. or 0.5 psi
Gauge accuracy	-	1 in. Hg. or 0.5 psi
Typical current draw (@ 13.8V)	-	0.13 A
Warning indicator max current	-	0.3 A

SERVICE AND REPAIR

DAKOTA DIGITAL offers complete service and repair of its product line. In addition, technical consultation is available to help you work through any questions or problems you may be having installing one of our units.

Should you ever need to send the unit back for repairs, please package the product in a good quality box along with plenty of packing material. Ship the product by UPS or insured Parcel Post. Be sure to include a complete description of the problem, your full name and address (street address preferred), and a telephone number where you can be reached during the day. An authorization number for products being returned for repair is not needed. Do not send any money. We will bill you for the repair charges. Any returns for warranty work must include a copy of the dated invoice or bill of sale.

ODYSSEY SERIES DIGITAL GAUGE LIMITED WARRANTY

DAKOTA DIGITAL (the Company) warrants to the ORIGINAL PURCHASER of this product that should it, under normal use and condition, be proven defective in material or workmanship within 24 MONTHS FROM THE DATE OF PURCHASE, such defect(s) will be repaired or replaced (at the Company's option) without charge for parts or labor directly related to repairs of the defect(s).

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), name, address, phone number, and specification of defects, transportation prepaid, to the factory. This Warranty is valid for the original purchaser only and may not be transferred.

This warranty does not cover nor extend to damage to vehicle electrical system. This Warranty does not apply to any product or part thereof which in the opinion of the Company has been damaged through alteration, improper installation, mishandling, misuse, neglect, or accident.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

The Company does not warrant that this product cannot be compromised or circumvented. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID TO THE PURCHASER FOR THE PRODUCT.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Dakota Digital

4510 W. 61ST St. N., Sioux Falls, SD 57107
Phone: (605) 332-6513 FAX: (605) 339-4106
www.dakotadigital.com
dakotasupport@dakotadigital.com