

REMOTE UP/DOWN DUAL WINDOW CONTROL

REM-5C

Thank you for purchasing the Remote Dual Window Control from Dakota Digital. These units have been designed to universally interface to virtually any power window regulator on the market. This system will raise and lower two power window systems individually.

Mounting:

The receiver module should be mounted up under the dash on either the drivers side or the passenger side of the vehicle. Plug in the 9 pin harness into the mating connectors on the control module harness. Route the antenna lead as high as possible behind the dash and as far across as possible. Do not coil it or wrap it around an existing wiring harness. The control module can be mounted next to the receiver module. The relays should be mounted into the doors to reduce the number of wires going through the door frame. Mount the relays so that the wires exit out the bottom. This will prevent water from collecting inside the relay.

Wiring:

Connect the RED power wire to a constant-on +12 volts and the black wire on the control module to chassis ground. The 14 gauge black and green wires on the relays should be connected according to the wiring diagram specific to your type of power window regulator. Connect the purple, orange, yellow, and brown wires from the controller to the 18 gauge black wires from the relays. The function of the wires is as follows:

- Purple wire -- activate relay to roll driver's window down.
- Orange wire -- activate relay to roll driver's window up.
- Yellow wire -- activate relay to roll passenger's window down.
- brown wire -- activate relay to roll passenger's window up.

Operation:

To operate the driver's window, press button #1. As long as the button is held, the window will continue to move. To stop the window at any point of its travel, simply release the button. The window direction can then be reversed by pressing button #1 again. The passenger's window can be operated in the same manner by pressing button #2.




Figure 1. Wiring diagram for Specialty Power Window's and Downs regulators.




Figure 2. Wiring diagram for Springfield Street Rod's regulators.

TERMINATE AND INSULATE ALL UNUSED WIRES.




Figure 3. Wiring diagram for Juliano's Interior Product's regulator.




Figure 4: Connection to window regulators with 4-wire switches.

BATTERY REPLACEMENT

Should the transmitter function become weak or erratic, the battery in the keychain transmitter may be weak. An indication of a weak battery is that the red indicator may have a dim glow to it when either button is pressed. If this occurs, first check the system by using the second transmitter provided. If the second transmitter function properly, replace the battery in the defective transmitter by the following method:

- A. Remove the small screw on the back of the transmitter case.
- B. Carefully separate the two case halves.
- C. Remove the battery noting the (+) and (-) position.
- D. Replace the battery with a new 12 volt type GP23A battery which is available at most electronic stores (Radio Shack, etc.).
- E. Carefully replace the top cover and refasten the screw.
- F. Check transmitter function. Should the transmitter still fail to function, it is possible the transmitter frequency is out of adjustment. To correct this problem, refer to "Transmitter Adjustment".

TRANSMITTER ADJUSTMENT

Should one of your transmitters fail to operate properly while the second works correctly and battery replacement has not corrected the problem, the transmitter frequency may be out of adjustment. To correct this, perform the following:

- A. Open the defective keychain transmitter as explained in battery replacement.
- B. Locate the small blue frequency fine-tune adjustment trimmer on the circuit board inside the transmitter.
- C. Using a small non-metallic adjustment tool, turn the adjusting screw inside the blue trimmer a 1/8 turn clockwise.
- D. Depress black button and check if the driver's door releases. If not, turn the adjustment screw an additional 1/8 turn clockwise and recheck. After turning the screw a total 1/2 turn clockwise, return to its starting position and repeat the adjustment by turning it counter-clockwise in the same manner.
- E. Once the system releases the door, stop and re-close the case. If the adjustment fails to correct the problem, return the defective transmitter for servicing.

REM-5C REMOTE UP/DOWN DUAL WINDOW CONTROL LIMITED LIFETIME WARRANTY

DAKOTA DIGITAL (the Company) warrants to the ORIGINAL PURCHASER of this remote control product that should any included control relay(s), electronic module, or transmitters under normal use and condition, be proven defective in material or workmanship DURING THE LIFETIME OF THE CAR IN WHICH IT WAS ORIGINALLY INSTALLED, such defect(s) will be repaired or replaced (at the Company's option) without charge for parts or labor directly related to repairs of the defect(s).

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the factory. This Warranty is valid for the original purchaser only and may not be transferred.

This Warranty does not cover batteries, nor extend to damage to vehicle electrical system. This Warranty does not apply to any product or part thereof which in the opinion of the Company has been damaged through alteration, improper installation, mishandling, misuse, neglect, or accident.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 30 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

The Company does not warrant that this product cannot be compromised or circumvented. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY THE PURCHASER FOR THE PRODUCT.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation if incidental or consequential damage so the above limitations or exclusion may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Dakota Digital

4510 W. 61ST St. N., Sioux Falls, SD 57107
Phone: (605) 332-6513 FAX: (605) 339-4106
www.dakotadigital.com
dakotasupport@dakotadigital.com

©Copyright 1995 Dakota Digital Inc.