

CONTROL BOX

Once the display panel is in place, mount the control box within the connecting cable's distance (approximately 3 feet) and secure to the underside of the dashboard. This case does not have to be mounted to metal, but by doing so you will provide a better ground to the control box. When connecting the display cable to the unit, be very sure to pay attention to the "up" side of the connector. Align the connector in the socket and press firmly into the control box. The connector locks will secure the connector.

Wiring the control box into the vehicle.

+12V

Connect the +12V terminal to the **RED wire** from the display panel.

Never connect this to a battery charger alone. It needs to have a 12 volt battery connected to it. Battery chargers have an unregulated voltage output that will cause the system to not operate properly.

GROUND

This is the main ground for the display system. Connect the **BLACK wire** from the display panel to this terminal.

Proper vehicle grounding is extremely important for the gauges to read and operate correctly. The engine block should have heavy ground cables to the battery, frame, and body. Failure to properly ground the engine block or the control box can cause incorrect or erratic operation.

DIMMING

The gauges are designed to dim down when the headlights are turned on. This is to reduce the display intensity at night so the gauges do not cause eye strain or reduced night vision. Connect the **WHITE wire** from the display system to this terminal.

The night brightness level is adjustable two different ways. The default method is to have the system to dim to a preset level when the lights are turned on. This brightness is adjusted by turning the shaft protruding from right side of the control box, next to the display system connector. Turning the shaft clockwise will decrease the brightness. The shaft will rotate $\frac{3}{4}$ turn from stop to stop. Do not attempt turn it past the stops. See DIM ADJ for a description of the second method.

DIM ADJ

The second method allows you to have a dash mounted control to vary the brightness while the headlights are on. This requires a 10k potentiometer or Dakota Digital's DIM-1 kit. A stock headlight rheostat will not work. The dash mount dimmer has two wires, one connects to the DIM ADJ terminal and the other connects to ground. To allow the dash mount dimmer to have full control, the shaft on the side of the control box must be turned fully counter-clockwise. The dash mount dimmer will only vary the display brightness when the DIMMING terminal has power.

SPEED

The **BROWN wire** from the display panel connects to the SPEED terminal.

This system can accept 4000 ppm – 128000 ppm speed signals. The sensor that Dakota Digital provides is an 8000 ppm type. The speedometer is fully adjustable and calibration is discussed in a later section.

TACH

Since the 88-91 pickups were not originally equipped with tachometers a wire will have to be routed from the distributor, through the fire wall, and to the control box. A length of yellow wire is supplied with the kit to do this.

The tachometer signal is connected to the terminal marked "TACH" on the control box for the instrumentation. Run a single wire from the control box to the engine's ignition system. On vehicles using a separate ignition coil, the wire connects to the terminal marked "DIST" (the negative side) on the coil. For GM HEI ignition equipped motors, connect the tach wire to the terminal marked "TACH". Do not connect the wire to the secondary or high voltage side of the ignition coil. To ensure that the ignition system does not interfere with any other dashboard functions, do not run the tachometer wire close to the other hookup lines, especially the speedometer input. Also **DO NOT USE solid core ignition wires with this dashboard system**. Solid core ignition wires cause a large amount of electromagnetic and radio frequency interference which can disrupt system operation.

WATER

This system is designed to use an original equipment General Motors water temperature gauge sender. Other senders will cause incorrect readings. The sender mounts on the engine block so that the end of the sensor is in the engine coolant flow.

Connect the **GREEN wire** from the display panel to the control box terminal marked WATER. If the water display shows "---" this indicates that the control box is sensing a short to ground or out-of-range error from the sender or sender wire. If the water display shows "EEE" this indicates that the control box is sensing an open circuit or out-of-range error from the sender or sender wire. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the correct sending unit is connected.

OIL

This system is designed to use an original equipment General Motors 80 psi oil pressure sender. Other senders will cause incorrect readings.

Connect the **GRAY wire** from the display panel to the control box terminal marked OIL. If the oil display shows "EE" this indicates that the control box is sensing an open circuit or out-of-range error from the sender. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the correct sending unit is connected.

FUEL

Connect the **PURPLE wire** from the display panel to the control box terminal marked FUEL. The fuel sender type is selected using the DIP programming switches located inside the control box. The settings are discussed later in the section on internal adjustments.

If the fuel display shows “—” this indicates that the control box is sensing a short to ground or out-of-range error from the sender or sender wire. If the fuel display shows “EE” this indicates that the control box is sensing an open circuit or out-of-range error from the sender. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the DIP programming switches are set correctly for the sending unit that is connected.

TRIP

The TRIP terminal is used for the trip odometer function, for setting the oil warning set point (see WRN), and for speedometer calibration (see SPEEDOMETER CALIBRATION). The TRIP input is activated by a ground connection. The push button switch supplied (or any normally open switch) is wired by connecting one terminal to TRIP and the other terminal to a ground. When the trip button is pressed, the odometer display will switch from full odometer mileage to the trip mileage or from the trip mileage to the full odometer mileage. When the trip mileage is shown a lower case “t” will be displayed to the left of the trip meter reading. “t 000.0”


RESET

The RESET terminal is used for the trip odometer function, for setting the water warning set point (see WRN), and for the speedometer calibration (see SPEEDOMETER CALIBRATION). The RESET input is activated by a ground connection. The push button switch supplied (or any normally open switch) is wired by connecting one terminal to RESET and the other terminal to a ground. When the reset button is pressed and held for a few seconds, the trip miles will be reset to zero. This will not affect the full odometer mileage.

CHECK


The check engine terminal is used with fuel injection ECM's to display engine problems and trouble codes. The CHECK input is activated by a ground signal from the ECM. Whenever the check input is grounded the system will display a lower case “c” to the right of the speedometer. When the ECM is placed into diagnostic mode trouble codes can be read by counting the flashes. Consult a service manual for the fuel injection system that you have for further information on trouble codes.

With some ECM's a 12 volt light bulb may need to be connected in addition to our CHECK input in order to provide proper current loading. In this case both the bulb and our display system indicator would both come on when the check engine wire was set.



BRAKE

The BRAKE terminal can be used as a brake system warning indicator. The BRAKE input is activated by a ground signal from the brake pressure switch on the master cylinder or from the parking brake set switch. Connect a wire from this terminal to the pressure switch on the master cylinder or consult a vehicle service manual to determine color and location of an existing wire. Whenever the BRAKE input is grounded the system will display a “b” to the left of the speedometer.



HI BEAM

The HI BEAM terminal is activated by a 12 volt signal from the headlight high beam wire. When the terminal has 12 volts, a dot will light up to the lower right of the speedometer display. An existing wire from the vehicle for the high beam indicator can be used or a new wire can be connected from the high beam side of the hi beam/low beam switch.

LEFT

The LEFT terminal is activated by a 12 volt signal from the turn signal switch. When this terminal has 12 volts, a dash will light up to the left of the speedometer display. An existing wire from the vehicle for the left turn indicator can be used or a new wire can be connected from the turn signal switch.

RIGHT

The RIGHT terminal is activated by a 12 volt signal from the turn signal switch. When this terminal has 12 volts, a dash will light up to the right of the speedometer display. An existing wire from the vehicle for the right turn indicator can be used or a new wire can be connected from the turn signal switch.

WRN

The WRN terminal is a dual function input and output. The output is ground-activated when the preset rpm limit is exceeded. This output can turn on a 4 Watt or smaller 12 volt bulb or can activate a relay to turn on a larger bulb. To wire a warning light to this output, connect one wire from the bulb to 12 volt accessory power and connect the other wire to the WRN terminal.

The input is used to set the water, oil, and rpm warning set points. See the Gauge Warning section for a description of how to set these.

MPH/KPH

The MPH/KPH terminal is activated by a 12 volt signal from a push button or toggle switch(not supplied). When the display system is in English mode (MPH & °F) by placing DIP programming switch #7 off, applying 12 volts to this terminal will convert the speed reading from MPH to KPH. The odometer will continue to accumulate miles correctly, but will display dashes. The bar speed display, if present, will not be affected.

When the display system is in Metric mode (KPH & °C) by placing DIP programming switch #7 on, applying 12 volts to this terminal will convert the speed reading from KPH to MPH. The odometer will continue to accumulate kilometers correctly, but will display dashes. The bar speed display, if present, will not be affected.


This input is provided to allow a convenient method of switching from MPH to KPH or from KPH to MPH while crossing borders or driving in areas with different speed markings.

GEAR SHIFT INDICATOR INPUTS

The PARK, REVERSE, NTRL, OVRDRV, DRIVE, 2nd, and 1st terminals are used for the gear shift indicator. The inputs are activated by a 12 volt signal from a gear shift sending unit. The indicator is built into every system but it will not light up unless a Dakota Digital GSS-1 or compatible gear shift sending unit is connected to tell it what gear the transmission is in. The gear shift sending unit is not included with the system and must be purchased separately.

When the gear shift sending unit is connected, a letter will light up to the right of the odometer to indicate what gear the transmission is in. Below is a chart showing the display indicators for each of the gears and a wiring diagram using Dakota Digital's GSS-1 adjustable gear shift sending unit. If you have a different gear shift sending unit, consult the wiring instructions supplied by the manufacturer.


PARK (P) –	P
REVERSE (r) –	r
NEUTRAL (n) –	n
OVERDRIVE (O) –	O
DRIVE (d) –	d
2nd (2) –	2
1st (1) –	1



CONTROL BOX TERMINAL STRIP DESCRIPTIONS

WATER TEMPERATURE SENDER INPUT	H2O	WATER
OIL PRESSURE SENDER INPUT	OIL	OIL
FUEL LEVEL SENDER INPUT	FUL	FUEL
CURRENTLY NOT USED	EX	EX
TRIP ODOMETER RESET INPUT	RS	RESET
TRIP ODOMETER SELECT INPUT	TR	TRIP
CHECK ENGINE INDICATOR INPUT	CK	CHECK
BRAKE SYSTEM WARNING INPUT	BK	BRAKE
HIGH BEAM INDICATOR INPUT	HI	HI BEAM
LEFT TURN SIGNAL INDICATOR INPUT	LT	LEFT
RIGHT TURN SIGNAL INDICATOR INPUT	RT	RIGHT
RPM WARNING OUTPUT/SET INPUT	RCL	WRN
SPEEDOMETER MPH/KPH CONVERSION INPUT	E/M	MPH/KPH
GEAR SHIFT INDICATOR PARK INPUT	P	PARK
GEAR SHIFT INDICATOR REVERSE INPUT	R	REVERSE
GEAR SHIFT INDICATOR NEUTRAL INPUT	N	NTRL
GEAR SHIFT INDICATOR OVERDRIVE INPUT	O	OVRDRV
GEAR SHIFT INDICATOR DRIVE INPUT	D	DRIVE
GEAR SHIFT INDICATOR 2nd INPUT	2nd	2nd
GEAR SHIFT INDICATOR 1st INPUT	1st	1st
TACHOMETER INPUT	TCH	TACH
VEHICLE SPEED SENSOR INPUT	SPD	SPEED
NIGHT DIMMING ADJUSTMENT INPUT	ADJ	DIM ADJ
GAUGE NIGHT DIMMING INPUT	DIM	DIMMING
+12 VOLT ACCESSORY POWER IN TO MAIN CHASSIS OR ENGINE GROUND	12V	+12V
	GND	GROUND

TO DISPLAY SYSTEM CONNECTOR



Insert cable with red stripe to right side.
Optional display power connector used only on STR4D/5D systems.

Setting up the control box

SPEEDOMETER CALIBRATION

The speedometer calibration is done using the TRIP and RESET switches. There are two different ways to calibrate the speedometer. The first method control box uses an auto-cal mode where you drive one mile (1 km for metric) and the system automatically adjusts the speedometer calibration. The second method allows you to adjust the speedometer up or down as you drive.

To enter the auto-calibration mode, begin with the key off. Press and hold both the trip and reset switches at the same time while the vehicle is started. The speed will display "CAL". Once the switches are released the control box will begin measuring. As you drive the odometer will display the number of pulses received from the sensor. If the reading stays at zero as you drive, then check the vehicle speed sensor and speed sensor wiring. Once you have driven exactly one mile (or km) press and hold both of the switches again. The system will calculate and store the new speed calibration. Once the switches are released the system will restart and go back to normal operation.

While the system is in the auto-cal mode the voltage, fuel, oil, and water gauges will remain blank will not change until the speed calibration is completed.

To enter the speedometer adjust mode, press and hold both the trip and reset switches at the same time while the system is on and operating. The switches will need to be held for about 4-6 seconds. The odometer will display "AdJUST" and the other gauges will function normally. Release the switches. Pressing and holding the TRIP switch will increase the speedometer reading. Pressing and holding the RESET switch will decrease the speedometer reading. Pressing and holding both the TRIP and RESET switches at the same time will store the current speed calibration and exit the speed adjust mode. While the system is in speed adjust mode the odometer will continue to accumulate normally, even though it is not displayed.

FUEL DIP SWITCH SETTINGS

The control box can read 5 different types of fuel senders. The DIP programming switches are located inside the control box, so the cover must be carefully removed to get access to the switches. Make sure the key is turned off before opening up the control box so that there is no power to the system. The switches labeled 1, 2, and 3 are used to select the different sender types. Once the switches have been set, replace the cover before turning the system on. The sender types are listed below, along with their corresponding empty and full resistance readings. If you do not know what type of sender you have, use an ohmmeter to measure the fuel sender resistance when it is full and empty. Ford fuel senders are not supported with this system.

Sender type	Empty R	Full R	Switch #1	Switch #2	Switch #3
GM 0-30 ohm	0 ohms	30 ohms	ON	ON	OFF
GM 0-90 ohm	0 ohms	90 ohms	OFF	ON	OFF
FORD	73 ohms	10 ohms			
VDO	10 ohms	180 ohms	OFF	OFF	OFF
SW/SUN	240 ohms	33 ohms	OFF	ON	ON

SW/SUN is the default setting when systems are shipped unless it was requested to be set differently.

TACHOMETER DIP SWITCH SETTINGS

The control box will work with 4, 6, 8, and 10 cylinder ignition systems. The DIP programming switches are located inside the control box, so the cover must be carefully removed to get access to the switches. Make sure the key is turned off before opening up the control box so that there is no power to the system. The switches numbers 5 and 6 select the number of engine cylinders. The settings are as follows:

Engine cylinders	Switch #5	Switch #6
4	ON	ON
6	OFF	ON
8	ON	OFF
10	OFF	OFF

Bar tach	Switch #4
6000 rpm	OFF
8000 rpm	ON

The default setting when systems are shipped from the factory is 8 cylinder.

In addition, the tachometer bar graph can be set to read 6000 rpm at full scale (switch #4 OFF) or 8000 rpm at full scale (switch #4 ON). This option would have been specified when the order was originally placed and the switch should be set to match the display system lens engraving. Systems with both a digital and bar graph tachometer are always set for 8000 full scale (switch #4 ON).

Because some systems have a digital speedometer with a bar graph tachometer directly above it (88 Chevy pickup) and some systems have a separate digital speedometer and digital tachometer, each having their own bar graph readout (94 Chevy pickup), switch #8 selects which style display system is being used. For 5-gauge systems with a bar graph tachometer directly above the speedometer, turn switch #8 OFF. For 6-gauge systems with a bar graph speedometer directly above the digital speedometer, **turn switch #8 ON**. This is set correctly at the factory before shipping to match the display system that it is paired with.

METRIC SELECTION DIP SWITCH SETTINGS

Switch #7 selects whether the temperature will be displayed in °F or °C and also sets the speedometer for MPH or KPH. For MPH/°F turn switch #7 OFF. For KPH/°C turn switch #7 ON. Changing switch #7 does not change the speedometer calibration. Speedometer calibration is discussed in another section. This switch will be set from the factory to match the display system lens engraving. If this is changed, a new lens should be purchased so that the labeling matches the gauge readings.

GAUGE WARNING FEATURE

The gauges have the built in feature to alert you when they are outside their normal operation range. The fuel display will flash whenever the fuel level is below 10% to indicate low fuel. The voltage gauge will flash whenever the system voltage is below 11.0 volts and the engine is running. The water gauge will flash whenever the temperature is higher than the water warning set point. The oil gauge will flash whenever the oil pressure is below the oil warning set point and the engine is running. The WRN output will be activated whenever the rpm warning set point is exceeded. A single lit bar on the right half of the rpm bar display shows the current rpm warning set point. The rpm warning set point can either be used as a shift indication or as a red line indication. The rpm warning output is triggered off the bar tach and is updated every 1/8 second.

The water, oil, and rpm warning set points are user adjustable. They are preset at the factory to 250 for water, 10 for oil, 4560 for 6000 bar tachs, and 6080 for 8000 bar tachs. The warning set points are adjusted using the TRIP, RESET, and WRN terminals.

To enter the warning adjust mode, ground the WRN terminal while the system is turned on. The speedometer will display "Adj". Release the ground from the WRN terminal. The current warning set points will be displayed. The RESET, TRIP, and WRN inputs adjust the water, oil, and rpm warning set points respectively. Once the set points have been changed, if an input is not activated for 8 seconds the values will be saved and the system will begin operating normally.

To change the water warning set point, press and hold the RESET button until the desired value is shown. The range is from 194 – 254°F in 2° increments (90 – 123°C).

To change the oil warning set point, press and hold the TRIP button until the desired value is shown. The range is from 2 – 30 psi in 2 psi increments.

To change the rpm warning set point, ground the WRN terminal until the desired value is displayed. For 0-6000 bar tachs, the range is from 2160-5760 rpm in 120 rpm increments. For 0-8000 bar tachs, the range is from 2880-7680 rpm in 160 rpm increments.

GAUGE SPECIFICATIONS

Gauge	Minimum reading	Maximum reading	Resolution
WATER	0°F (0°C)	299°F (148°C)	1 - 2°
OIL	0 psi	80 psi	1 psi
FUEL	0% (empty)	99% (full)	1 - 3%
VOLT	8.0 volts	18.0 volts	0.1 volt ±0.1
SPEED	0 mph (kph)	255 mph (kph)	1
ODOMETER	00000.0 miles (km)	99999.9 miles (km)	0.1
TRIP METER	000.0 miles (km)	999.9 miles (km)	0.1
TACH bar	400 rpm	6000 rpm or 8000 rpm	120 or 160
TACH digital	400 rpm	9990 rpm	10

Power requirements: 11 – 15 volts dc
(Battery charges cannot be used for powering or testing this system.)

TROUBLESHOOTING GUIDE

This is a list of some problems and their solutions which may be encountered when installing your instrumentation system. If you cannot determine what the problem is or how to solve it, please call our technical assistance line (605) 332-6513.

*** A note on vehicle grounding. ***

The most common cause of problems with electric gauges is poor ground connections. The engine block has the highest ground currents of any point in the vehicle. The ignition system, electric gauge senders, starter, alternator, etc. all use the engine block for a ground point. Since the alternator is grounded directly to the engine block all ground currents in the entire vehicle must pass through the engine block while the engine is running. A weak or loose connection can cause all kinds of random problems that may difficult to track down. The engine block should have heavy ground straps to both the chassis and the body. The main negative cable from the battery should be connected directly to the engine block.

Symptom	Possible Problem	Solution
System does not light up.	Control box may not be getting power.	Check if the control box has 12 volts connected to it. Do not use a battery charger to power the system. Check the fuse inside the control box. If it is blown, replace with a 2 amp fuse.
	The display system may not be getting power.	Insert the connector on the display system wiring harness into the slot on the side of the control box. Be sure the pins line up properly. Check the display system wiring harness for broken or cut wires.
	The control box may have an internal problem	Return the control box to Dakota Digital with a description of the problem and a phone number.
A display shows dashes.	The sending unit for that display is not connected to the control box.	Check the wire from sending unit to the control box for breaks. Make sure that the sending unit is wired to the correct terminal. Make sure the sending unit is grounded properly.
One display does not light up.	If the circle in the upper right corner of the display is white, the display is cracked or broken	Return the display panel to Dakota Digital for repair. Include a phone number and address.
The tachometer will not show a reading.	The control box is not connected to the engine properly	Make sure the control box is connected to your particular system properly.

Symptom	Possible Problem	Solution
The tachometer reading is incorrect.	<p>The tachometer signal wire is loose or broken.</p> <p>The control box is not set up for the proper number of cylinders or the proper tach range.</p>	<p>Check the connections at both ends of the wire.</p> <p>Refer to the Internal Adjustments section of the installation manual to set the control box properly.</p>
The speedometer will not show a reading.	<p>The speed sending unit is not connected to the control box properly.</p> <p>The speed sending unit being used is not compatible with the control box.</p> <p>The speed sending unit is not connected to the transmission properly.</p> <p>The sending unit wire is picking up noise from nearby wires.</p>	<p>Check that both speed sending unit wires are connected to the control box properly.</p> <p>Use the speed sending unit supplied with the display system.</p> <p>Check that sender is mounted properly.</p> <p>Check that transmission has the appropriate internal parts.</p> <p>Isolate the sending unit wire from motor and ignition wires.</p>
The fuel display reads backwards, incorrectly, or does not change.	<p>The control box may be set for the wrong type of fuel sender.</p> <p>The fuel sender may not be connected to the control box properly.</p> <p>The fuel sender may not be operating properly.</p> <p>The fuel sender may have a non-standard resistance range.</p>	<p>Refer to the Internal Adjustments section of the installation manual to ensure that the settings match your fuel sender.</p> <p>Check the connections at both ends of the fuel sender wire.</p> <p>Make sure the fuel sender is grounded properly.</p> <p>Check the fuel sending unit with a mechanical gauge or an electrical multi-meter.</p> <p>If the proper resistance range setting is not available with the control box settings, replace the fuel sender with a different style.</p>
The oil or water display reading is incorrect.	<p>The engine block may not be grounded to the chassis frame or body properly.</p> <p>The sending unit wire is picking up noise from nearby wires.</p> <p>The sending unit is not compatible with the control box</p> <p>The sending unit has failed.</p>	<p>Use heavy ground cables from the battery to the engine block.</p> <p>Make sure both ends of the cable have clean metal-to-metal connections.</p> <p>Use a braided ground strap to ground the engine block to the chassis.</p> <p>Use a large braided ground strap to ground the engine block to the body or fire wall.</p> <p>Isolate the sending unit wire from motor and ignition wires.</p> <p>Use the appropriate GM gauge sending unit.</p> <p>Replace the sending unit</p>

Symptom	Possible Problem	Solution
The gear shift indicator does not light up.	The optional gear shift sending unit is not connected to the control box.	Connect the sending unit to the control box using the instructions supplied with the sending unit.
The gear shift indicator does not operate properly.	The gear shift sending unit is not connected properly.	Check the connections to the transmission linkage and to the control box. Connect 12 volts to the sending unit power wire.
The colored bulbs in the display panel for turn signals and high beam do not light up. (not found on all units)	The LED bulbs are not connected into the auto's electrical system. (these are not wired into the display system control box)	Connect the wires found on the back of the aluminum panel to your cars electrical system as explained in the Optional Indicators section of the manual.
The internal turn signal and high beam indicators do not light up.	The control box is not connected to the vehicle's electrical system properly.	Check the wires connected to the HIGH, LEFT, and RIGHT terminals on the control box.
The check engine indicator does not operate properly.	The control box is not connected to a TPI control module.	This feature is designed to work with engine control systems that provide an active low signal.
The check engine indicator stays on all of the time.	The Engine Control Module (ECM) needs to see the load of a light connected to it.	Connect a light or similar load to the ECM along with the control box.
Trip select and trip reset functions do not operate properly.	Select and reset switches are not connected to the control box. The wrong type of switch is being used.	Momentary push-button or toggle switches must be connected to the TRIP and RESET terminals as described in the Trip meter section of the installation manual The switch terminal connected to the control box should normally be open. When the the switch is activated, the terminal should make contact to ground.
The display system starts up in the demonstration mode and remains in it.	The TRIP terminal is constantly connected to ground.	Disconnect or replace the trip select switch.

Dakota Digital

4510 W. 61ST St. N., Sioux Falls, SD 57107
 Phone: (605) 332-6513 FAX: (605) 339-4106
www.dakotadigital.com
dakotasupport@dakotadigital.com