




MCL-30K-TCH

Thank you for purchasing the Dakota Digital MCL-30K-TCH gauge for your Harley Davidson Touring bike. This kit is designed to be a replacement for all touring models, from 1996 – 2003. This is part of a six gauge package for touring models so you can add additional gauges as you choose.

INSTALLATION

First read and familiarize yourself with all of the components and this manual. The first step is to remove the seat and disconnect the negative side of the battery, as with any electronic install. Once the battery is disconnected you are ready to start.

Remove the outer fairing for FLHT models; this will vary from model to model, please follow the service manual to expose the wiring and gauges. Road Glide (FLTR) models will not need the outer fairing removed.




Ultra (FLHT) with outer removed

Remove Factory Gauge

Now you are ready to start unplugging and removing the gauge.

ULTRA FLHT (batwing fairings)

Remove the clamps that hold the Speed and Tach in place with a screw driver or wrench depending on application, and remove the gauges.



Remove nuts/screws and clamp to remove factory gauges

ROAD GLIDE FLTR

You will need to remove the speedometer and tachometer instrument bezel. To do this, remove two small screws on the left and right side of the bezel. Then lift up on the back of the bezel and slide the tab that is under the ignition switch out from under the switch cover, see photos below of ignition switch cover removed to show detail. Now unplug the gauge connections (cable where applicable). Remove switch, and unplug the idiot lights so the bezel can be completely removed for easier installation of the new gauges. Remove the clamp(s) that hold the gauges to the bezel and remove the gauges and grommets/gaskets.



Picture of tab (switch cover removed)

Bezel removed

Gauges/Grommets removed


Install New Gauges

Next you are ready to install the new gauges into the fairing. The new tachometer comes supplied with a new gasket and clamp. Install the gauge and secure using the supplied clamp and gasket. Be sure the alignment tab on the clamp lines up with the notches in the fairing. Some fairings may only have one notch, line up at least one tab on the clamp with the notch in the fairing, this will insure the gauges are centered and aligned correctly.



Tachometer




WIRING



First locate your tachometer connector in the factory wiring harness that were unplugged from the original tach gauge. The wires needed for the Dakota Digital tachometer should all be found here. The factory connector can be cut off or the new wires can be spliced into the harness. Not all wires may be present on all years or models.

Clock Memory connection

You will need to locate a fused, constant +12V battery power wire for the orange, clock memory wire. The long, orange, clock memory wire is located on the tachometer gauge plug. Check your service manual or use a voltmeter or test light to find and verify a constant power location. One common location to pick up the constant power is pin #10 on the radio. This should be a Red w/Orange wire that is fused to the battery.



Night dimming

The BLUE wire in the MCL-30K-TCH harness controls can be connected to other Dakota Digital MCL-3k or MCL-30K gauges. The tachometer will automatically dim the other gauges when it gets dark (the tachometer has a sensor that activates the dimming feature when ambient light is low).

FUNCTION SWITCH

If an MCL-30K-SPD gauge is installed, then the factory speedometer push button switch is used as the main function switch, otherwise a push button switch should be connected and mounted to allow access to all of the gauge features. The function switch is used for setup and for adjusting the clock.

The function switch can also be used to change the tachometer display. If an MCL-30K-SPD gauge is also installed, be sure the speedometer is displaying the odometer to avoid resetting any of the other settings before attempting to change the tachometer. Press and hold the switch for about 4 seconds to change the tach menu. Press and hold the switch for about 6 seconds to reset the high RPM recall while it is displayed. The tachometer only has two display modes as follows:

	<u>TACH MENU</u>		
CLOCK	>	12:00	12 hour clock
HI RPM	>	0000	high rpm recall

GAUGE SETUP AND CALIBRATION

The function switch, discussed above, is used to enter setup mode for all of the gauges. If you are only installing one or a couple Dakota Digital MCL-3K gauges, then setup may seem a little strange since they are designed to work as a set. The first step in the setup procedure is to select which gauge you are going to adjust. Each gauge will either show a number or a label. If the gauge is showing a label then that gauge will be selected to enter setup. All of the other gauges will exit setup and allow the selected gauge to be changed. To get into setup, press and hold the function switch while turning the key on. Press and release the switch to advance through the menus below, when on the desired option press and hold the switch to select setup for that particular gauge/function.

	speed	tach	oil psi	oil temp	fuel	volt
1 st	- 1 -	[L	- 1 -	- 1 -	- 1 -	- 1 -
2 nd	SPD	- 2 -	- 2 -	- 2 -	- 2 -	- 2 -
3 rd	- 3 -	tCH	- 3 -	- 3 -	- 3 -	- 3 -
4 th	- 4 -	- 4 -	PSI	- 4 -	- 4 -	- 4 -
5 th	- 5 -	- 5 -	- 5 -	F or [- 5 -	- 5 -
6 th	- 6 -	- 6 -	- 6 -	- 6 -	FUL	- 6 -
7 th	- 7 -	- 7 -	- 7 -	- 7 -	- 7 -	ULt
8 th	- 8 -	- 8 -	- 8 -	- 8 -	- 8 -	- 8 -

FACTORY DEFAULT SETTINGS FOR SETUP MENUS

Below is a list of factory gauge settings and what can be adjusted in the setup menus. You can calibrate and adjust the tachometer as often as you wish, however it should only need to be set once. The only gauge that may require setting after the initial install is the Clock function on the tachometer so it is the first setup menu.

Tachometer

Engine Cylinders	2
Signal Type	12 HI (12V ignition signal)
Night Dimming	1 (darkest)
Display Update	3 (fastest 1/8 sec.)
RPM Warning	5500 (range 2200-9900)

TACHOMETER SETUP

Main Menu	Sub Menu	Description
CL		set clock time
ELH	n 19HL	set night dimming level
	t CAL	set engine cylinder setting
	uPdRtE	set rpm update rate for digital readout
	uJAr-n	set rpm shift warning point
	GEAR	transmission gear programming
	5 19nAL	select 12 HI (normal) or 5 LO (low voltage) tach signal

The gauge can be set to read from 1-15 cylinder ignition signals. It can also be set to read either 12 volt tach signals or 5 volt tach signals found on some engine computers. The digital tachometer update rate can be adjusted between slow, mid, and fast. The rpm warning/shift point can be adjusted from 2200 – 9900. The tachometer will read from 350 – 9,990 rpm.

Press and hold the switch while turning the key on. Release the switch. Press and release the switch until “ELH” is displayed, then press and hold switch until “-” is displayed. The rpm display will show “5EL” and the lower display will show “night”. Press and release the switch to move through the different menus, press and hold the switch to select a menu option.

Note: The tachometer calibration may require you to hold the switch while starting the bike, only if you are going to adjust/set the GEAR programming since you will have to ride the bike. Some ignition systems may disrupt power to other circuits causing the gauge to reset, this is why you must hold the switch while starting if you are setting up the GEAR display. All other gauge functions, and gauges, can be set without running the engine

CL Clock setup

The time is displayed on the smaller display below the RPM. It will not light up until the orange wire is powered.

- To set the clock, press and hold the switch while turning the key on. Release the switch.
- The RPM display should show “CL”, press and hold switch until “-” is displayed.
- Release the switch. The lower display will show the current hours.
- Press and release the switch to change the hours, press and hold the switch to change the minutes.
- Release the switch. The lower display will show the current minutes.
- Press and release the switch to change the minutes, press and hold the switch to save this and exit setup.

n 19HL Night dimming

Your display system has a dimming feature that dims the display intensity. Normally the system is at full brightness for daytime viewing. The tachometer has a light sensor that will provide a signal to the other gauges to reduce the brightness at night. The level of darkness before the gauges dim can be adjusted in the tachometer setup.

- Press and release the switch until “n 19HL” is displayed, then press and hold the switch until “-” is displayed.
- Release the switch. The update setting will be displayed. (1=late(darkest), 2=mid, 3=early(lightest), OFF).
- Press and release the switch until the desired setting is displayed.
- Press and hold the switch until “-” is displayed to save the setting.

t CAL Engine cylinder setup

- Press and release the switch until “t CAL” is displayed, then press and hold the switch until “-” is displayed.
- Release the switch. The current cylinder setting will be displayed.
- Press and release the switch until the desired setting is displayed.
- Press and hold the switch until “-” is displayed.

uPdRtE Display update setup

The display update will select how quickly the tachometer reading will respond.

- Press and release the switch until “uPdRtE” is displayed, then press and hold the switch until “-” is displayed.
- Release the switch. The update setting will be displayed. (1=slow, 2=mid, 3=fast).
- Press and release the switch until the desired setting is displayed.
- Press and hold the switch until “-” is displayed to save the setting.

uJAr-n Rpm warning setup

- Press and release the switch until “uJAr-n” is displayed, then press and hold the switch until “-” is displayed.
- Release the switch. The current warning point will be displayed.
- Press and release the switch until the desired setting is displayed.
- Press and hold the switch until “-” is displayed to save the setting.

(Tachometer Setup Continued)

GEAR Gear indicator setup

This tachometer has a single digit display for gear position. The gauge can learn the positions based on speed and rpm so no sensors are needed, just what you've already connected. It will work with 4, 5, 6 or 7 speed transmissions. To program the gear positions, begin at a section of road where you can gradually shift through all of the gears. Press and hold the switch while turning the key on and starting the engine. Once the engine is running, release the switch.

- Press and release the switch until "LCH" is displayed. Press and hold the switch until " - " is displayed.
- Press and release the switch until "GEAR" is displayed, press and hold the switch until " - " is displayed.
- The message will show "LD LCH" if the engine rpm is below 1500, or "LD SPD" if the vehicle speed is below 5.
- Begin driving in 1st gear. The display should show GEAR 1 and the "1" should be flashing. Drive at a steady speed until the "1" stops flashing, it should only take about 20 seconds if the speed and RPMs are steady.
 - *Optionally: If the gear does not stop flashing you can manually override and jump to the next gear by pressing and releasing the switch to store the gear position quicker.*
- Shift to 2nd gear and drive at a steady speed. The display will change to a flashing "2".
- Wait until the "2" stops flashing. then "3" should start flashing, shift to the next gear and continue.
 - *Optionally: If the gears do not stop flashing you can manually override and jump to the next gear by pressing and releasing the switch to store the gear position quicker.*
- Repeat this through each gear. When you are done, come to a complete stop or press and hold the switch until the display shows "SELEP".
- Turn the key off and then on again to restart the gauges in normal operation, verify the gear position by riding through each gear and seeing if positions agree.

5 IGNAL Tach signal setup

- Press and release the switch until "5 IGNAL" is displayed, then press and hold the switch until " - " is displayed.
- Release the switch. The setting will be displayed. (12 HI or 5 LD). 12 HI is the normal setting.
- Press and release the switch until the desired setting is displayed.
- Press and hold the switch until " - " is displayed.

Tachometer Troubleshooting guide.

Problem	Possible cause	Solution
Gauge will not light up	Red wire does not have power. Black wire is not getting a good ground. Gauge is damaged.	Connect to a location that has power. Connect ground to a different location. Return gauge for repair. (see instructions)
Clock will not light up	Orange wire does not have power.	Connect to a location that has constant power.
Clock will not keep time	Orange wire does not have constant power.	Connect to a location that has constant power.
Gauge lights up, but tach will only show zero.	Yellow wire is not connected properly. Ignition system not grounded properly. Gauge is not grounded properly. Tach signal type is not set correctly. Gauge is not calibrated	Check connection from yellow wire to tach signal wire. Check engine and ignition system grounds. Check gauge and engine grounds. Change the tach signal type (see instructions). Gauge must be recalibrated (see instructions).
Tach reading is erratic or jumps around.	Tach signal wire is loose or broken. Poor ground connection.	Check all wire connections and inspect wire for breaks. Check ground connection on tachometer, engine, and ignition system.
	Update rate is too fast.	Reset display update speed slower.
Tach reading is incorrect.	Gauge is not calibrated correctly.	Gauge must be calibrated (see instructions).
Gear indicator is always -	Gears not programmed.	Program gear indicator in setup. (see instructions)
Gauge will not dim.	Night dimming is turned off or too low.	Change "night" setting in setup. (see instructions).
Gauge remains dim at all times.	Night dimming is turn too high. Light sensor at bottom of gauge is covered.	Change "night" setting in setup. (see instructions). Make sure the lower part of the lens is not covered.
Cruise Engage indicator does not work.	Loose or incorrect connection to indicator wire.	Check that the appropriate indicator wire has about 12 volts when the indicator should be off and about 0 volts when the indicator should be on.

WIRING COLOR CODE FOR TACHOMETER:

Color on GAUGE	Stock harness color	Function
GREEN	none	switch input
BLUE	none	night dimming
WHITE	WHITE/GREEN	output speed signal
BLACK	BLACK	ground for gauge
RED	ORANGE/WHITE	+12 volt power with key on
ORANGE	RED/ORANGE	+12V battery power for clock
YELLOW	PINK	tach signal input
WHITE/GREEN	GREEN/RED	cruise set indicator

SERVICE AND REPAIR

DAKOTA DIGITAL offers complete service and repair of its product line. In addition, technical consultation is available to help you work through any questions or problems you may be having installing one of our products. Please read through the Troubleshooting Guide. There, you will find the solution to most problems.

Should you ever need to send the unit back for repairs, please call our technical support line, (605) 332-6513, to request a Return Merchandise Authorization number. Package the product in a good quality box along with plenty of packing material. Ship the product by UPS or insured Parcel Post. Be sure to include the RMA number on the package, and include a complete description of the problem with RMA number, your full name and address (street address preferred), and a telephone number where you can be reached during the day. Any returns for warranty work must include a copy of the dated sales receipt from your place of purchase. Send no money. We will bill you after repair.

Dakota Digital 24 Month Warranty

DAKOTA DIGITAL warrants to the ORIGINAL PURCHASER of this product that should it, under normal use and condition, be proven defective in material or workmanship within 24 MONTHS FROM THE DATE OF PURCHASE, such defect(s) will be repaired or replaced at Dakota Digital's option.

This warranty does not cover nor extend to damage to the vehicle's systems, and does not cover removal or reinstallation of the product. This Warranty does not apply to any product or part thereof which in the opinion of the Company has been damaged through alteration, improper installation, mishandling, misuse, neglect, or accident.

This Warranty is in lieu of all other expressed warranties or liabilities. Any implied warranties, including any implied warranty of merchantability, shall be limited to the duration of this written warranty. Any action for breach of any warranty hereunder, including any implied warranty of merchantability, must be brought within a period of 24 months from date of original purchase. No person or representative is authorized to assume, for Dakota Digital, any liability other than expressed herein in connection with the sale of this product.

⚠WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov



4510 W. 61st St. North
Sioux Falls, SD 57107
www.dakotadigital.com
dakotasupport@dakotadigital.com

Phone (605) 332-6513
Fax (605) 339-4106

Copyright 2011 - Dakota Digital, Inc.