

Dakota Digital

SERIES 3

VACUUM FLUORESCENT DIGITAL DASHBOARD

The latest in digital dashboard technology for the street rodder, car, and truck enthusiast.

INSTALLATION AND OPERATION MANUAL

Please read this before beginning installation or wiring.

MODEL VFD3X SYSTEMS

Dakota Digital

4510 W. 61ST St. N., Sioux Falls, SD 57107
Phone: (605) 332-6513 FAX: (605) 339-4106
www.dakotadigital.com
dakotasupport@dakotadigital.com

©Copyright 2002 Dakota Digital Inc.

There are two methods for mounting the display panel into your dash. The first method is to cut an opening in the dash the size of the inside lip and “sandwich” the dash between the bezel and the mounting plate. The second method is to cut an opening in the dash the size of the outside of the bezel and mount the entire display assembly from the back using six #10 or #8 mounting studs attached to the back of the dash.

Figure 1 shows method #1 with a steel or thin fiberglass dash. Figure 2 shows method #1 with a thick fiberglass or wood dash. Figure 3 shows method #2.




Figure 1. Mounting method 1 with thin dash.




Figure 2. Mounting method 1 with thick dash.

Method #1

Cut a rectangular hole where you want the dash mounted that is 1-11/16" tall x 17" long. Next round the ends to match the bezel. The hole should be 18-11/16" long in the center from end to end.

Remove the six screws that secure the mounting plate to the display panel. Next remove the eight screws which attach the bezel to the mounting plate.

For thin dash material, place several strips of foam tape on the front of the mounting plate. These will be compressed down when it is mounted to the dash.

Place the lens and bezel into the opening in your dash. Place the mounting plate up from behind the dash and secure it to the bezel using the eight pan head screws. The screws will go through the lens and thread into the bezel. Do not over tighten these screws. Just tighten them so that the bezel is held in place securely.

Next attach the display system to the mounting plate using the six screws. Make sure that the display panel is aligned properly with the flat gray cable coming out on the top side.




Figure 3. Mounting method 2.

Method #2

Cut a rectangular hole where you want the dash mounted. The hole should be at least 2" tall x 17" long rectangular with the ends rounded so that the center of the hole is 19" long.

Mount the six #8 or #10 studs to the back of your dash so that they line up with the display system mounting holes. You can place the display system into the dash and use a marker or pencil to mark the stud locations.

Next place the display system onto the studs and tighten it up from the back.

CONTROL BOX

Once the display panel is in place, mount the control box within the connecting cable's distance (approximately 3 feet) and secure to the underside of the dashboard. This case does not have to be mounted to metal, but by doing so you will provide a better ground to the control box. Align the connector in the socket and press firmly into the control box. The connector locks will secure the connector.

Wiring the control box into the vehicle

+12V

Connect the +12V terminal to accessory power from the fuse panel or vehicle wiring harness. This terminal should have power when the key is on or in accessory position. In addition to powering the display system, this is also where the voltmeter gauge senses the vehicle electrical system voltage.

Use 18 AWG or larger wire to ensure the system gets good power.

Never connect this to a battery charger alone. It needs to have a 12 volt battery connected to it. Battery chargers have an unregulated voltage output that will cause the system to not operate properly.

GROUND

This is the main ground for the display system. A wire should be run from this terminal to the vehicle's main ground location at the chassis or engine block. Do not use the dash or a dash support brace for the ground connection.

Use 18 AWG or larger wire to ensure sufficient grounding. Proper vehicle grounding is extremely important for the gauges to read and operate correctly. The engine block should have heavy ground cables to the battery, frame, firewall, and body. Failure to properly ground the engine block or the control box can cause incorrect or erratic operation.

DIMMING

The gauges are designed to dim down when the headlights are turned on. This is to reduce the display intensity at night so the gauges do not cause eye strain or reduced night vision. Connect this to the tail light or parking light circuit so that it has 12 volts whenever the headlights are on. When this terminal does not have power the display system will be at full brightness. When power is applied, the display dims to an adjustable level. The night brightness level is adjustable two different ways.

The default method is to have the system to dim to a preset level when the lights are turned on. This preset brightness is adjusted in the setup menu "DIM". See DIM ADJ for a description of the second method.

DIM ADJ

The second method allows you to have a dash mounted control to vary the brightness while the headlights are on. This requires a 10k potentiometer or Dakota Digital's DIM-1 kit. A stock headlight rheostat will not work. The dash mount dimmer has two wires, one connects to the DIM ADJ terminal and the other connects to ground. The dash mount dimmer will only vary the display brightness when the DIMMING terminal has power.

SPEED

The vehicle speed sensor (VSS) connects to this to tell the system how fast the vehicle is moving. For two wire speed sensors, like the one Dakota Digital supplies with this system, the polarity of the wires does not matter. Connect one wire to ground and the other to the speed terminal. The speed sensor ground wire should be brought back to the control box to ensure a proper signal is received. Twisting the ground and signal wires around each other provides an additional level of interference protection. The speed signal wire should not be routed along side ignition or other high current or high voltage wires.

For vehicles which already have a vehicle speed signal, tap into the VSS wire and connect it to the speed terminal. You may have to consult a vehicle service manual or wiring diagram to determine wire color and location.

This system can accept 4000 ppm – 128000 ppm speed signals. The sensor that Dakota Digital provides is an 8000 ppm type. The speedometer is fully adjustable and calibration is discussed in a later section. ***Failure to calibrate the speedometer may cause your odometer mileage to increase very rapidly if the speedometer is reading too fast.***

TACH

The gauge system has both a digital readout and a bar graph tachometer. Connect the tach terminal to the ignition system. On vehicles using a separate ignition coil, connect to the negative side of the coil. The negative side of the coil will be the wire that goes to the points or electronic ignition module. For GM HEI ignition equipped motors, connect the tach terminal to the terminal marked "TACH" or on some systems, to a single white wire with a spade terminal on it. On MSD ignition systems, connect to the TACH output terminal. With magneto system connect to the kill wire for the tach signal. Do not connect the TACH terminal to the secondary, or high voltage side, of the ignition coil. To ensure that the ignition system does not interfere with any other dashboard functions, do not run the tachometer wire along side any other sender or input wires. **DO NOT USE SOLID CORE SPARK PLUG WIRES WITH THIS DASHBOARD SYSTEM.** Solid core ignition wires cause a large amount of electromagnetic and radio frequency interference which can disrupt the system operation.

The tachometer is compatible with almost all gasoline engines. The engine cylinder selection, display update rate, tach signal type, and rpm warning point can be adjusted in the setup menu under "TACH". If a diesel engine is being used and the alternator has a tach output, then Dakota Digital's DSL-1 interface will convert the alternator signal to operate the tachometer.

WATER

The water temperature sender included with this system must be used. Other senders will cause incorrect readings. The sender mounts on the engine block or into the intake manifold so that the end of the sensor is in the engine coolant flow. The sender gets its electrical ground connection to the engine block through its threads. *Do not use Teflon tape or thread sealant on the sender threads.* Doing so can cause incorrect readings or cause the gauge to display an out of range indication. A sender with 1/8 NPT thread size is normally included along with adapters to go to 1/4, 3/8, and 1/2 NPT. If the engine you have requires a metric or non-standard thread size you can contact Dakota Digital for availability or check your local auto parts dealer or hardware store for an adapter.

A single wire should be run from the terminal on top of the water sender to the control box terminal marked WATER. If your wiring harness already has a wire routed through the vehicle for the water temperature then it may be used. Do not route the water sender wire along

side a spark plug wire or other high current or high voltage wires. Doing so can cause incorrect or erratic gauge readings.

If the water display shows “---“ this indicates that the control box is sensing a short to ground or out-of-range error from the sender or sender wire. If the water display shows “EEE” this indicates that the control box is sensing an open circuit or out-of-range error from the sender or sender wire. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the correct sending unit is connected. The sending unit should be stamped with “VDO” and “150°C”.

Replacement sender part numbers are:

	Dakota Digital	VDO equivalent
1/8" NPT	SEN-04-1	323 057
3/8" NPT	SEN-04-2	323 059
½" NPT	SEN-04-4	323 060
12mm	SEN-04-6	323 092

OIL

The oil pressure sender included with this system must be used. Other senders will cause incorrect readings. If the sender mounting location is too small or is restricted, then pipe fittings may be required to move the sender away from the restrictions. Oil pressure line may also be used to remote mount the sender to the fire wall. The sender gets its electrical ground connection to the engine block through its threads. *Do not use Teflon tape or thread sealant on the sender threads.* Doing so can cause incorrect readings or cause the gauge to display an out-of-range indication. If the sender is being remote mounted away from the engine, make sure the sender case is grounded well. The sender has 1/8 NPT thread size. If the engine you have requires a different thread size you will need to use an adapter to convert the thread size. Adapters can be found at your local auto parts dealer or hardware store.

A single wire should be run from the terminal on top of the oil sender to the control box terminal marked OIL. If your wiring harness already has a wire routed through the vehicle for the oil sender then it may be used. Do not route the oil sender wire along side a spark plug wire or other high current or high voltage wires. Doing so can cause incorrect or erratic gauge readings.

If the oil display shows “—“ this indicates that the control box is sensing a short to ground or out-of-range error from the sender or sender wire. If the oil display shows “EE” this indicates that the control box is sensing an open circuit or out-of-range error from the sender. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the correct sending unit is connected.

Replacement sender part numbers are:

	Dakota Digital	VDO equivalent
	SEN-10-2	360 003

FUEL

The fuel gauge sending unit is not normally supplied with the system. The display system will usually use the fuel sending unit that is already in the tank. The sending units that are compatible with this system are as follows: GM, Ford, VDO, and Stewart Warner. It is also possible to program in a custom setting for senders that are not pre-programmed into the system. The Stewart Warner sender type is used by most after-market gauges. A single wire should be run from the fuel sender to the control box terminal marked FUEL. If your wiring harness already has a wire routed through the vehicle for the fuel sender then it may be used. If using a wire from an existing harness, make sure that the wire does not have power. The fuel sender gets power from the control box only. Fuel senders get their ground from the sender

mounting plate. Make sure that a ground wire is connected from one of the sender mounting bolts to the vehicle frame.

The fuel sender type is selected using the setup menu under "FUEL". The settings are discussed later in the section on internal adjustments.

The fuel gauge will initially display "FL" until the fuel sender type has been set. If the fuel display shows "—" this indicates that the control box is sensing a short to ground or out-of-range error from the sender or sender wire. If the fuel display shows "EE" this indicates that the control box is sensing an open circuit or out-of-range error from the sender. If either indication remains on the display, inspect the sender wire for damage, check the routing of the sender wire, check the sending unit grounding, and check that the sender selection is set correctly for the sending unit that is connected.

SW 1 or Message switch

The SW 1 terminal is used for selecting the various speed, distance, warning, and performance displays and also for entering the setup menu. The SW 1 input is activated by a ground connection. The push button switch supplied (or any normally open switch) is wired by connecting one terminal to SW 1 and the other terminal to a ground. When the button is pressed and released, the message display will change. When the button is pressed and held for a few seconds, any re-settable information displayed will be zeroed. When the service miles and hour meter are displayed, pressing and holding the switch will only zero the service miles.

SW 2 or Demo switch

The SW 2 terminal is used for zeroing the hour meter display and also for entering the demonstration mode. The SW 2 input is activated by a ground connection. The push button switch supplied (or any normally open switch) is wired by connecting one terminal to SW 2 and the other terminal to a ground. When the service miles and hour meter are displayed, pressing and holding the switch for a few seconds will zero the hours.

To enter DEMO mode, press and hold the switch while turning the key on.

CHECK

The check engine terminal is used with fuel injection ECM's to display engine problems and trouble codes. The CHECK input is activated by a ground signal from the ECM. Whenever the check input is grounded the system will display switch to the warning messages and "ENGINE" will be highlighted. This message can be cleared by pressing and holding switch 1.

When the ECM is placed into diagnostic mode trouble codes can be read by counting the flashes. Consult a service manual for the fuel injection system that you have for further information on trouble codes.

With some ECM's a 12 volt light bulb may need to be connected in addition to our CHECK input in order to provide proper current loading. In this case both the bulb and our display system indicator would both come on when the check engine wire was set.

BRAKE

The BRAKE terminal can be used as a brake system warning indicator. The BRAKE input is activated by a ground signal from the brake pressure switch on the master cylinder or from the parking brake set switch. Connect a wire from this terminal to the pressure switch on the master cylinder or consult a vehicle service manual to determine color and location of an existing wire. Whenever the BRAKE input is grounded the system will switch to the warning messages and "BRAKE" will be highlighted. This message can be cleared by pressing and holding switch 1.

CRUISE

The CRUISE terminal can be used as a cruise engaged indicator. The CRUISE input is activated by a ground signal from a compatible cruise control harness. Whenever the CRUISE input is grounded the system will switch to the message display and "CRUIS" will be highlighted.

WAIT

The WAIT terminal can be used as a wait to start or glow plug indicator. The WAIT input is activated by a 12 volt signal from the glow plugs. Whenever the WAIT input is powered the system will switch to the warning messages and "WAIT" will be highlighted. This message can be cleared by pressing and holding switch 1.

4x4

The 4x4 terminal can be used on four wheel drive vehicles. The 4x4 input is activated by a ground signal from a switch on the transfer case. Connect a wire from this terminal to the switch on the transfer case. Whenever the 4x4 input is grounded the system will switch to the message display and "4x4" will be displayed on the top left side. When signal turns off, the system will display "4x2" on the message display.

HI BEAM

The HI BEAM terminal is activated by a 12 volt signal from the headlight high beam wire. When the terminal has 12 volts, an indicator will be turned on in the lower right of the message display. An existing wire from the vehicle for the high beam indicator can be used or a new wire can be connected from the high beam side of the hi beam/low beam switch.

LEFT

The LEFT terminal is activated by a 12 volt signal from the turn signal switch. When this terminal has 12 volts, an arrow will light up to the left of the message display. An existing wire from the vehicle for the left turn indicator can be used or a new wire can be connected from the turn signal switch.

RIGHT

The RIGHT terminal is activated by a 12 volt signal from the turn signal switch. When this terminal has 12 volts, an arrow will light up to the right of the message display. An existing wire from the vehicle for the right turn indicator can be used or a new wire can be connected from the turn signal switch.

SHIFT

The SHIFT terminal is an output for a relay or small light. The output is ground-activated when the preset rpm limit is exceeded. This output can turn on a 4 Watt or smaller 12 volt bulb or can activate a relay to turn on a larger bulb. To wire a warning light to this output, connect one wire from the bulb to 12 volt accessory power and connect the other wire to the SHIFT terminal.

GEAR SHIFT INDICATOR INPUT

The GEAR terminal is used for the gear shift indicator. The indicator is built into every system but it will not light up unless a Dakota Digital GSS-1000/2000/5000 gear shift sending unit is connected to tell it what gear the transmission is in. The gear shift sending unit is not included with the system and must be purchased separately. The GEAR terminal will connect to the FIRST terminal on a GSS-1000 or to the 1-wire terminal on a GSS-2000 or GSS-5000. Follow the instructions in the GSS manual for use with a single wire display system.

The gear display is selected in the setup menu under "GEAR". The choices are no gear display, standard transmission, or overdrive transmission.

When the gear shift sending unit is connected, the current gear letter will be highlighted on the message display below the mileage readings.

MESSAGE DISPLAYS

Screen 1

ODOMETR 000000 with gear select set to NONE
TRIP 000.0

000000 T 000.0 with gear select set to OVRDRV
P R N O D 2 1

000000 T 000.0 with gear select set to PRND21
P R N D 2 1

Screen 2

000 00.0 00.0 mph with ¼ time displayed
HI 0-60 1/4

000 00.0 000 mph with ¼ speed displayed
HI 0-60 1/4

HI 0-100 1/4 kph version (distance still ¼ mile)

Screen 3

x1x2x3x4x5x6x7x8
Hx0000 Wx0000

Screen 4


0000 000 000.0 mph version
SRVC KPH HOUR

SRVC MPH HOUR kph version

Screen 5

4x4 WAIT CRUIS
BRAKE ENGINE

CHECK ENGINE INDICATOR INPUT
 BRAKE SYSTEM WARNING INPUT
 HIGH BEAM INDICATOR INPUT
 LEFT TURN SIGNAL INDICATOR INPUT
 RIGHT TURN SIGNAL INDICATOR INPUT
 4 WHEEL DRIVE INDICATOR INPUT
 RPM WARNING/SHIFT OUTPUT
 1-WIRE GEAR INDICATOR INPUT
 WAIT TO START INPUT
 CRUISE ENGAGED INPUT
 CURRENTLY NOT USED
 CURRENTLY NOT USED



"HEARTBEAT" STATUS LIGHT
 WATER TEMPERATURE SENDER INPUT
 OIL PRESSURE SENDER INPUT
 FUEL LEVEL SENDER INPUT
 NIGHT DIMMING ADJUSTMENT INPUT
 TACH SELECT SWITCH INPUT
 SPEED SELECT SWITCH INPUT
 GAUGE NIGHT DIMMING INPUT
 TACHOMETER INPUT
 VEHICLE SPEED SENSOR INPUT
 2k PPM SPEED OUTPUT
 +12 VOLT ACCESSORY POWER IN
 TO MAIN CHASSIS OR ENGINE GROUND

GAUGE SYSTEM FEATURES

Mileage readings

- Million mile odometer
- Re-settable trip mileage (0-999.9)
- Re-settable service mileage (0-9999)

Performance readings

- High speed recall. This is reset at power up and can be manually reset.
- High rpm recall. This is reset at power up and can be manually reset.
- 0-60 mph (0-100kmh) time. This is reset automatically when speed is zero.
- ¼ mile time. This is reset automatically when speed is zero.
- ¼ mile end speed. This is reset when the ¼ mile time restarts.

Hour meter

- Re-settable hours (0-999.9)

English/metric conversion

- Alternate speed can be displayed on message display.

Special tachometer displays

- A bar tach can be shown on the message display.

Demonstration mode

- Holding switch 2 while turning on the key will start the system going through a preset sequence of readings. To exit the demo mode, turn the key off.

WIRE COLOR CODE FOR GM WIRING HARNESS

On the connector that originally plugged into the instrument cluster:

Function	Color
+12 volt	Pink/Black or Pink
Ground	Black
Oil sender	Tan or no wire if mechanical
Water sender	Dark green
Fuel sender	Pink or light brown (should not have power)
Left turn	Light blue
Right turn	Dark blue
High beam	Light green
Brake warn	Tan/white or tan

Setting up the control box

SETUP MENU

Main Menu	Sub Menu	DESCRIPTION
SPEED	AUTO	auto calibrate speed
	ADJUST	adjust calibrate speed
	UNIT	select mph F or kph C units
	MPH F	
	KPH C	
	OUTPUT	speed output rate
	2K PPM	
	4K PPM	
TACH	ENGINE	set engine cylinder setting
	UPDATE	set rpm update rate
	WARN	set rpm shift warning point
	SIGNAL	select normal or low voltage tach signal
	NORMAL LO VLT	
FUEL	SENDER	set fuel sender type
	CUSTOM	
	GM 30	
	GM 90	
	GM 250	
	F 10	
	F 150	
	V 180	
	SW 33	
	CUSTOM TEST	calibrate custom fuel sender display sender ohm reading
WATER	UNIT	select mph F or kph C units
	WARN	set high temp warning point
	TEST	display sender ohm reading
OIL	WARN	set low psi warning point
	TEST	display sender ohm reading
DIM		change preset night dimming
GEAR	NONE	no gear display
	PRND21	without overdrive
	OVRDRV	with overdrive
DONE		restart system with new settings.

SPEEDOMETER SETUP

Press and hold SW 1 switch while turning the key on and starting the engine. Once the engine is running, release the switch. When "SPEED" is displayed, press the switch again and then release it. The message display should switch between "AUTO", "ADJUST", "UNIT", and "OUTPUT".

METRIC SELECTION

If you are setting the system up for metric displays, press the switch when "UNIT" is displayed.

Press and release the switch until "KPH C" is displayed.

Press and hold the switch until "DONE" is displayed.

SPEED CALIBRATION

There are two methods for calibrating the speedometer, auto cal and adjust. Either one can be used. Auto cal requires that you have one measured mile marked out (km for metric). Adjust requires you to follow another vehicle going at a set speed or timing your self over a mile to determine your speed.

Auto Cal

When "AUTO" is displayed press and release the switch. The speedometer will display "SEt", the fuel, volt, oil, and water will display normally, and the message display will show zeroes. You should now begin driving the measured mile. The message display will count the number of pulses received from the sensor. The message display cannot be used to determine when a mile has been driven. Once you reach the end of your marked mile, press the switch again. The calibration is now done.

Adjust

When "ADJUST" is displayed press and release the switch. The system will restart with "ADJUST" on the message display. The fuel, volt, oil, water, and tach will operate normally. The speedometer will show the speed reading. Begin driving at a known speed. Press switch 1 to increase the speedometer reading and press switch 2 to decrease the speedometer reading. When the speedometer is correct you can stop and restart the system. The new calibration will be saved.

Speed Output

If a speed output signal is need for an ECM or cruise control, the 2k ppm terminal can be used. This will normally provide a 2000 pulse per mile signal after the speedometer has been calibrated. If you need a 4000 pulse signal, go to the SPEED setup menu and then select "OUTPUT".

Press and release the switch until 4K PPM is displayed.

Press and hold the switch until "DONE" is displayed.

FUEL SETUP

The control box can read 7 different types of preset fuel senders and can also be programmed for a custom fuel sender setup. Press and hold SW 1 switch while turning the key on. Release the switch. When "FUEL" is displayed, press the switch again and then release it. The message display should switch between "SENDER", "CUSTOM", and "TEST".

Sender Selection

When "SENDER" is displayed press and release the switch.

Press and release the switch until the desired setting is shown. The preset types are listed in the table below.

Press and hold the switch until “DONE” is displayed.

Sender type	Menu	Empty R	Full R
GM 0-30 ohm	GM 30	0 ohms	30 ohms
GM 0-90 ohm	GM 90	0 ohms	90 ohms
GM 40-250 ohm	GM 250	40 ohms	249 ohms
FORD 73-10 ohm	F 73	73 ohms	10 ohms
FORD 20-150 ohm	F 150	20 ohms	150 ohms
VDO 10-180 ohm	V 180	10 ohms	180 ohms
SW/SUN 33-240	SW 33	240 ohms	33 ohms
User settable	CUSTOM	User settable	User settable

Custom Fuel setup

You will either need to have the sender out of the tank, or begin with the tank empty and add fuel during the setup.

When “CUSTOM” is displayed press and release the switch.

The speed display will show the current sender resistance seen by the control box.

The message display will show “SET 00”. Move the float to the empty position and then press and release the switch.

The message display will show “SET 33”. Release the switch and move the float to 1/3 full and then press and release the switch.

The message display will show “SET 66”. Release the switch and move the float to 2/3 full and then press and release the switch.

The message display will show “SET 99”. Release the switch and move the float to the full position and then press and release the switch. The new sender is now stored under the “CUSTOM” sender selection.

The message display will show begin going back through the main menu. When “FUEL” is displayed, press and release the switch.

When “SENDER” is displayed press and release the switch.

The current sender setting will now be displayed. Press and release the switch until “CUSTOM” is displayed.

Press and hold the switch until “DONE” is displayed.

TACHOMETER SETUP

The control box can be set to read from 1-15 cylinder ignition signals. It can also be set to read either 12 volt tach signals or 5 volt tach signals found on some engine computers. The digital tachometer update rate can be adjusted between slow, mid, and fast. The rpm warning/shift point can be adjusted from 2200 – 14800. The tachometer will read from 350 – 17,500 rpm. At rpm’s above 9990 the reading will be displayed as rpmx1000 (12,000=12.00).

Press and hold SW 1 switch while turning the key on. Release the switch. When “TACH” is displayed, press the switch again and then release it. The message display should switch between “ENGINE”, “UPDATE”, “WARN” and “SIGNAL”.

Engine cylinder setup

When “ENGINE” is displayed press and release the switch.

The current cylinder setting will be displayed.
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

Display update setup

When "UPDATE" is displayed press and release the switch.
The update setting will be displayed. (1=slow, 2=mid, 3=fast)
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

Rpm warning setup

When "WARN" is displayed press and release the switch.
The current warning point will be displayed on the rpm display.
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

Tach signal setup

When "SIGNAL" is displayed press and release the switch.
The setting will be displayed. (NORMAL or LO VOLT)
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

WATER TEMP SETUP

Press and hold SW 1 switch while turning the key on. Release the switch. When "WATER" is displayed, press the switch again and then release it. The message display should switch between "UNIT", "WARN" and "TEST".

METRIC SELECTION

If you are setting the system up for metric displays, press the switch when "UNIT" is displayed.

Press and release the switch until "KPH C" is displayed.
Press and hold the switch until "DONE" is displayed.

Temp warning setup

When "WARN" is displayed press and release the switch.
The current warning point will be displayed.
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

OIL PRESSURE SETUP

Press and hold SW 1 switch while turning the key on. Release the switch. When "OIL" is displayed, press the switch again and then release it. The message display should switch between "WARN" and "TEST".

Pressure warning setup

When "WARN" is displayed press and release the switch.
The current warning point will be displayed.
Press and release the switch until the desired setting is displayed.
Press and hold the switch until "DONE" is displayed.

DIM PRESET SETUP

Press and hold SW 1 switch while turning the key on. Release the switch. When “DIM” is displayed, press the switch again and then release it. 88 or 888 will be displayed on the fuel, oil, volt, and water displays. The system will dim down to the current preset level.

Press and hold SW 1 until the desired night brightness is shown. When the system reaches its lowest brightness it will start over again at full brightness.

Once the night brightness is correct, press SW 2 to save it.

GEAR DISPLAY SETUP

Press and hold SW 1 switch while turning the key on. Release the switch. When “GEAR” is displayed, press the switch again and then release it. The current gear display selection will be shown.

Press and release the switch until the desired setting is shown.

Press and hold the switch until “DONE” is displayed.

TROUBLESHOOTING GUIDE

This is a list of some problems and their solutions which may be encountered when installing your instrumentation system. If you cannot determine what the problem is or how to solve it, please call our technical assistance line (605) 332-6513 or email to dakotasupport@dakotadigital.com.

* A note on vehicle grounding. *

The most common cause of problems with electric gauges is poor ground connections. The engine block has the highest ground currents of any point in the vehicle. The ignition system, electric gauge senders, starter, alternator, etc. all use the engine block for a ground point. Since the alternator is grounded directly to the engine block all ground currents in the entire vehicle must pass through the engine block while the engine is running. A weak or loose connection can cause all kinds of random problems that may difficult to track down. The engine block should have heavy ground straps to both the chassis and the body. The main negative cable from the battery should be connected directly to the engine block.

Symptom	Possible Problem	Solution
System does not light up.	Control box may not be getting power.	Check if the control box has 12 volts connected to it. Do not use a battery charger to power the system.
	Control box may not be getting a ground. The display system may not be getting power.	Check if the control box has a proper ground connection. Insert the connector on the display system wiring harness into the slot on the side of the control box. Be sure the pins line up properly. Check the display system wiring harness for broken or cut wires.
	The control box may have an internal problem	Contact Dakota Digital's service department with a description of the problem.

Symptom	Possible Problem	Solution
One display does not light up at all, all others work correctly.	The display panel corner of the display is white or the display is cracked or broken	Return the display panel to Dakota Digital for repair. Include a phone number and address.
The tachometer will not show a reading.	The control box is not connected to the engine properly	Make sure the control box is connected to your particular ignition system properly.
The tachometer reading is incorrect.	The tachometer signal wire is loose or broken. The control box is not set up for the proper number of cylinders or the proper tach range.	Check the connections at both ends of the wire. Refer to the Tach Setup section of the installation manual to set the control box properly.
The speedometer will not show a reading.	The speed sending unit is not connected to the control box properly. The speed sending unit being used is not compatible with the control box. The speed sending unit is not connected to the transmission properly. The sending unit wire is picking up noise from nearby wires.	Check that both speed sending unit wires are connected to the control box properly. Use the speed sending unit supplied with the display system. Check that sender is mounted properly. Check that transmission has the appropriate internal parts. Isolate the sending unit wire from motor and ignition wires.
The speedometer is reading too fast or too slow.	The speedometer is not calibrated.	Refer to the Speed Calibration section of the installation manual.
With the engine running and the vehicle sitting still, the speedometer reads higher than zero.	A tachometer wire is too close to the speed sensor wire. There is a ground problem between the speed sensor and the control box.	Reroute or isolate the tachometer wire away from the speed wire. Make certain the ground wire for the speed sensor is connected directly to the control box ground.
A display shows "EE"	Sending unit for that gauge is not connected to the control box. Sending unit is not getting grounded. On the water or oil, the sending unit is not the correct type.	Check the wire from sending unit to the control box for breaks. Make sure that the sending unit is wired to the correct terminal. Make sure the sending unit is grounded properly. Make sure the water and oil senders have clean threads. Use the water and oil senders that were supplied with the system.
A display shows "--"	The sending unit wire for that gauge is shorted to ground.	Repair or replace shorted wire.
Fuel displays "FL"	The control box is set to an invalid fuel sender setting.	Refer to "Fuel Setup" section of the installation manual to ensure that the settings match your fuel sender.

Symptom	Possible Problem	Solution
The fuel display reads backwards, incorrectly, or does not change.	The control box may be set for the wrong type of fuel sender.	Refer to "Fuel Setup" section of the installation manual to ensure that the settings match your fuel sender.
	The fuel sender may not be connected to the control box properly.	Check the connections at both ends of the fuel sender wire. Make sure the fuel sender is grounded properly.
	The fuel sender may not be operating properly.	Check the fuel sending unit with an electrical multi-meter.
	The fuel sender may have a non-standard resistance range.	If the proper resistance range setting is not available with the control box settings, replace the fuel sender with a different style.
The oil or water display reading is incorrect.	The engine block may not be grounded to the chassis frame or body properly.	Use heavy ground cables from the battery to the engine block. Make sure both ends of the cable have clean metal-to-metal connections. Use a braided ground strap to ground the engine block to the chassis. Use a large braided ground strap to ground the engine block to the body or fire wall.
	The threads are not grounding to the engine block.	Make sure no thread sealant is used on any of the threads.
	The sending unit wire is picking up noise from nearby wires.	Isolate the sending unit wire from motor and ignition wires.
	The sending unit is not compatible with the control box	Use the sending unit provided the display system.
	The sending unit has failed.	Return the sending unit to Dakota Digital for replacement.
The gear shift indicator does not light up.	The optional gear shift sending unit is not connected to the control box.	Connect the sending unit to the control box using the instructions supplied with the sending unit.
The gear shift indicator does not operate properly.	The gear shift decoder is not connected properly.	Check the connections to the transmission linkage and to the control box. Check gear shift decoder Installation manual.
The internal turn signal and high beam indicators do not light up.	The control box is not connected to the vehicle's electrical system properly.	Check the wires connected to the HIGH, LEFT, and RIGHT terminals on the control box.
The check engine indicator does not operate properly.	The control box is not connected to a TPI control module.	This feature is designed to work with engine control systems that provide an active low signal.

Symptom	Possible Problem	Solution
The check engine indicator stays on all of the time.	The Engine Control Module (ECM) needs to see the load of a light connected to it.	Connect a light or similar load to the ECM along with the control box.
The Function switches do not operate properly.	The push-button switches are not connected to the control box. The wrong type of switch is being used.	Momentary push-button or toggle switches must be connected to the SW1 and SW2 terminals as described in the manual. The switch terminal connected to the control box should normally be open. When the the switch is activated, the terminal should make contact to ground.
The display system starts up in the demonstration mode and remains in it.	Sw 2 terminal is constantly connected to ground.	Disconnect or replace the SW2 switch.

CLOCK

Wiring instructions for VFD systems with a clock built in.

Introduction:

The clock displays the current time in 12 hour format with an AM/PM indicator. The AM/PM indicator appears as a dot that will be displayed in the upper left corner. The dot will be on every other 12 hour period (on during AM and off during PM). The high brightness display matches our other Odyssey and STR series gauges and has the same night brightness dimming capability. Features included are:

- Quartz accuracy.
- Night dimming feature.
- Very low standby power to prevent battery drain.
- High Visibility VFD display for sunlight readability.

Operation:

The gauge needs the red, orange, and black wires connected to operate. The red wire should have switched 12 volt power from an ACC. point on the fuse panel. The orange wire should have constant 12 volt power. The black wire should be connected to a good ground point. When the blue wire has 12 volts, it will dim the display for night viewing.

Setting the time:

Using a small, thin object such as a pen or hairpin, press "set" buttons through front lens access holes. The access holes are on the right side of the lens. Top "set" button advances hours, bottom "set" button advances minutes.

Wiring:

- | | | |
|--------|---|---|
| BLACK | - | connect to a good ground point in the vehicle. |
| RED | - | connect to switched 12 volt power point.
(An accessory terminal will work for this.) |
| ORANGE | - | connect to a constant 12 volt power point.
(This will keep the correct time.) |
| BLUE | - | connect to the tail light circuit. |

SERVICE AND REPAIR

DAKOTA DIGITAL offers complete service and repair of its product line. In addition, technical consultation is available to help you work through any questions or problems you may be having installing one of our products. Please read through the Troubleshooting Guide. There, you will find the solution to most problems.

Should you ever need to send the unit back for repairs, please call our technical support line, (605) 332-6513, to request a Return Merchandise Authorization number. Package the product in a good quality box along with plenty of packing material. Ship the product by UPS or insured Parcel Post. Be sure to include the RMA number on the package, and include a complete description of the problem with RMA number, your full name and address (street address preferred), and a telephone number where you can be reached during the day. Any returns for warranty work must include a copy of the dated sales receipt from your place of purchase. Send no money. We will bill you after repair.

Dakota Digital Limited Lifetime Warranty

DAKOTA DIGITAL warrants to the ORIGINAL PURCHASER of this product that should it, under normal use and condition, be proven defective in material or workmanship for the lifetime of the original vehicle it was installed in, such defect(s) will be repaired or replaced at Dakota Digital's option.

This warranty does not cover nor extend to damage to the vehicle's systems, and does not cover removal or reinstallation of the product. This Warranty does not apply to any product or part thereof which in the opinion of the Company has been damaged through alteration, improper installation, mishandling, misuse, neglect, or accident.

This Warranty is in lieu of all other expressed warranties or liabilities. Any implied warranties, including any implied warranty of merchantability, shall be limited to the duration of this written warranty. No person or representative is authorized to assume, for Dakota Digital, any liability other than expressed herein in connection with the sale of this product.

Dakota Digital

4510 W. 61ST St. N., Sioux Falls, SD 57107
Phone: (605) 332-6513 FAX: (605) 339-4106
www.dakotadigital.com
dakotasupport@dakotadigital.com

©Copyright 2002 Dakota Digital Inc.