

# VFD3-91C-IMP-D Installation Guide

Fits 1991-93 Chevy Caprice with factory digital speedometer

1991-1993 Buick Roadmaster

1991-1992 Oldsmobile Custom Cruiser



After removing the stock cluster from the vehicle remove the clear lens and black angled adapter plate.

Remove the screws holding the lens onto the aluminum can of the Dakota Digital system.



Place the clear lens and adapter plate on top of the Dakota Digital lens and use the provided screws to assemble.

Install display panel into the dash using the stock hardware.

See main instruction manual for the remainder of installation.

### Indicator Light Chart - Stock vs. Dakota Digital

	Battery	Antilock	Brake	Door Open	Gate Ajar	Infl Rest	Low Coolant	Low Wash	Low Oil	Oil	Seatbelt	Serv. Eng. Soon	Temp	Check Shocks	Check PS	Cruise	Low Fuel
91-93 Chevy Caprice	✓	✓	✓	✓	✗	✓	✓	✗	✓	✓	✓	✓	✓	✗	✗	✗	✗
91-93 Buick Roadmaster	✓	✓	✓	✗	✓	✓	✗	✗	✗	✓	✓	✓	✓	✓	✓	✓	✗
91-92 Olds Custom Cruiser	✓	✓	✓	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗	✗	✓
Dakota Digital	Display Flash	✗	✓	✗	✗	✗	✗	✗	✗	Display Flash	✗	✓	Display Flash	✗	✗	✓	Display Flash

✓ = Has      ✗ = Does Not Have

**⚠ WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



4510 W. 61st St. North  
Sioux Falls, SD 57107  
www.dakotadigital.com

Phone (605) 332-6513  
Fax (605) 339-4106

dakotasupport@dakotadigital.com Copyright 2011 - Dakota Digital, Inc.